

Rockwell Micro850 - Free Tag Names


Supported Series: Rockwell Micro820/850

Website: http://www.ab.com

HMI Setting:

Parameters	Recommended	Options	Notes
PLC type	Rockwell Micro850 - Free Tag Names		
PLC I/F	RS232		
Baud rate	38400	1200 ~ 38400	
Data bits	8		
Parity	None	None,Even,Odd	
Stop bits	1		
PLC sta. no.	1	0 ~ 254	

PLC Setting:






Support Device Type:

Data type	EasyBuilder data format	Memo
Bool	bit	
Byte	16-bit BCD, Hex, Binary, Unsigned	8-bit
SInt	16-bit BCD, Hex, Binary, Signed	8-bit
USInt	16-bit BCD, Hex, Binary, Unsigned	8-bit
Word	16-bit BCD, Hex, Binary, Unsigned	16-bit
Int	16-bit BCD, Hex, Binary, Signed	16-bit
UInt	16-bit BCD, Hex, Binary, Unsigned	16-bit
DWord	32-bit BCD, Hex, Binary, Unsigned	32-bit
DInt	32-bit BCD, Hex, Binary, Signed	32-bit
Real	32-bit Float	32-bit
UDInt	32-bit BCD, Hex, Binary, Unsigned	32-bit
Lint	64-bit Signed	64-bit
String	ASCII Object	Length=word

Note: EBPro V6.03.02 or later supports 64 bits data type **(cMT Series only)**, but please note that the address limit range is 48 bits in maximum.


How to Import Tags:

1. Click [Tag Editor].







2. Right-click [Global-Variables] and select [New data type].



3. Click [Paste].




4. Launch "Connected Components Workbench" software, select and copy the tags under [Global Variables]. Note that the IO address cannot be copied and can only be manually created.






5. Paste the copied tags and click [OK].




6. Enter [Name], click [OK], and then click [Save to default]. The tags are now successfully created.






Building Struct:


1. After importing the tags, the data type of Struct is shown as in the following figure, please build the corresponding tag under Struct-Defined.



2. Right click on [Struct-Definded] and then select [New data type].




3. Enter the [Data type] in the [Name] field, and then click [Add].






4. Enter the same information in the [Name] and [Data Type] fields as shown in the original factory software, and then click [OK].



5. Upon completion click [OK] and then click [Save to default] to finish building Struct.





Wiring Diagram:

Diagram 1

cMT Series	cMT3071 / cMT3072 / cMT3090 / cMT3103 /cMT3151
eMT Series	eMT3070/ eMT3105 / eMT3120 / eMT3150
MT-iE	MT8073iE / MT8102iE
MT-XE	MT8092XE
MT-iP	MT6103iP/ MT8102iP

	НМІ	
	COM1	COM3
	RS232 9P Female	RS232 9P Female
Rx	2	8
Tx	3	7
GND	5	5

Diagram 2

cMT Series	cMT-SVR / cMT-G01 / cMT-G02 / cMT-HDM / cMT-FHD	
mTV	mTV	
MT-iE	MT8070iE / MT6070iE / MT8100iE / MT8121iE / MT8150iE /	
	MT8071iE / MT6071iE / MT8072iE / MT6072iE / MT8073iE /	
	MT8101iE / MT8102iE / MT8103iE	
MT-XE	MT8121XE / MT8150XE / MT8090XE	





Diagram 3

MT-iE	MT8050iE/ MT8053iE
MT-iP	MT6051iP/ MT8051iP / MT6071iP / MT8071iP

